Racking System Overview

Components of the AirCool Storage System

- Collapsible rack (3 required for 12 body boards)
- Roller tracks (2 required per racking level)
- Body boards

Safety Warning

- All racking supplied is NOT designed to be moved whilst in use.
- Care must be taken by users when erecting the racking as it is heavy.
- Racking should be set up by at least 2 persons.
- Maximum weight per level 100kg.
- The total weight of each rack is 39kg

*Image for illustration purposes only. Flooring not included.

Scan to watch set up and dismantle videos

info@flexmort.com flexmort.com +44 (0)8455 333561

Assembling the Rack

Repeat steps 1 - 4 for each rack that you need to assemble

1

Hold racking upright, apply castor brakes and unclip the straps.

2

Release the brakes from one side and fully extend the opposite side.

3

- Apply all brakes and add two rollers per row.
- The front of the rack has a double bar. The stopper end should be at the rear of the rack.
- The rollers will secure onto the racking in three places.

4

- Add the two long bars to the top of the rack, front and back.
- Add body boards.

Dismantling the System

1. Remove the body boards.
2. Remove the rollers and the top bars.
3. Holding vertically, release the brake from one end and push the racking back together to collapse – secure with the strap.